

# **Attention**

## **Maytag, Magic Chef, Amana RV Customers**

### **To order Replacement Parts**

**Maytag Customer Service  
555 Exchange Court  
Aurora, IL 60504**

**Toll Free #..... 1 - 877 800 6390**


**Fax # ..... 1 - 630 236 5380**

**Direct # ..... 1 - 630 236 5374**

### **To Receive Warranty Labor**

**Maytag Customer Service  
Warranty Department  
P. O. Box 4970  
Cleveland TN 37320-4970**


**For Help with Product Usage, Installation or Warranty  
Information, please call  
1 - 800 - 544 - 5513**



**Model Number: CLY1620BDB**  
**BOM/Serial #: CLY1620BDB**  
**Graphic Title: TOP & GAS CONTROLS**


Image	Key	Part Number	Description	Substitution	Qty.
1	1	74004288	SCREW (6ABX3/8-SN)		2
1	1	74009853	BURNER, OVEN (W/SHUTTER)		1
1	2	7101P356-60	SCREW	7101P126-60	2
1	2	74004583	BURNER, TOP (R.R.)		1
1	2	74004584	BURNER, TOP (L.R.)		1
1	3	7101P356-60	SCREW	7101P126-60	1
1	3	74004582	BURNER, TOP (FRT)		1
1	4	8007P020-60	GROMMET		8
1	5	74007277	GRATE (BLK)		2
1	6	74004234	FITTING, HALF UNION		1
1	7	74003942	KNOB, BURNER (BLK)		2
1	7	74003941	KNOB, BURNER (BLK)		1
1	8	74009858	KNOB, THERMOSTAT (BLK)		1
1	9	74009852	BURNER, PILOT RV		1
1	10	74009856	PIPE, MANIFOLD		1
1	11	74004235	REGULATOR, PRESSURE	12001285	1
1	13	8003P008-60	BUMPER		2
1	14	74009857	SCREW, THERMOSTAT		1
1	14	7507P049-60	FLANGE, T STAT		1
1	14	74009854	TUBING 3/16		1
1	14	74009855	THERMOSTAT		1
1	14	74009850	TUBING 1/4		1
1	15	74003323	TOP, MAIN (BLK)	74007287	1
1	16	1555279	NUT, 1/4" LOXIT		1
1	16	74009864	ELBOW BLOCK ASSY.		1
1	17	12002245	KIT, VALVE & SCREW (MUELLER)		2
1	17	12002246	KIT, VALVE & SCREW (MUELLER)		1
1	18	74009848	BAFFLE, RV BURNER		1
1	19	7432P077-60	IGNITER, TOP		1
1	19	7104P002-60	FASTENER, PUSH RING RV		1
1	20	74003327	EXTENSION, FLASHTUBE (FRT)		1
1	20	74003326	EXTENSION, FLASHTUBE (REAR)		2
1	21	7112P068-60	CLIP		2
1	22	74002413	IGNITER		1
1	22	5111A719-60	WIRE, IGNITER		1

<b>Image</b>	<b>Key</b>	<b>Part Number</b>	<b>Description</b>	<b>Substitution</b>	<b>Qty.</b>
1	23	74003944	KNOB, IGNITER (BLK)		1
1	24	7101P356-60	SCREW	7101P126-60	2
1	24	3807F462-45	SUPPORT, TOP BURNER		1
1	25	74003325	CUP/TUBE ASSY.		1
1	26	3604F211-45	SHIELD		1
1	27	7103P030-60	NUT, WING		1



**Model Number: CLY1620BDB**  
**BOM/Serial #: CLY1620BDB**  
**Graphic Title: OVEN**

Image	Key	Part Number	Description	Substitution	Qty.
1	1	74003998	CLIP, MAIN TOP		2
1	2	7112P065-60	CLIP, OVEN BOTTOM		2
1	2	7101P124-60	SCREW WWASHER (CHR)	74003976	2
1	2	2205F016-19	BOTTOM, OVEN		1
1	3	4006W075-80	FLUE BOX ASSY		1
1	3	7101P124-60	SCREW WWASHER (CHR)	74003976	3
1	4	7112P004-60	CLIP, THERMOSTAT		1
1	5	7101P356-60	SCREW	7101P126-60	2
1	5	74001747	SCREW		2
1	5	74009862	BACK, MAIN		1
1	5	74009861	INSULATION		1
1	6	7103P109-60	T-NUT (RV HINGE)		4
1	6	7101P301-60	SCREW #6 X 1/2		4
1	6	7103P082-60	NUT	M0282007	4
1	6	74002812	TRIM, SIDE (BLK) (RT)		1
1	6	74002813	TRIM, SIDE (BLK) (LT)		1
1	7	7803P051-60	SPRING, OVEN DOOR		2
1	8	74009863	BOTTOM, BURNER BOX		1
1	9	7101P301-60	SCREW #6 X 1/2		2
1	9	7103P109-60	T-NUT (RV HINGE)		2
1	10	74003342	BOTTOM, MAIN		1
1	10	7101P356-60	SCREW	7101P126-60	2
1	11	74007296	PANEL, MANIFOLD (BLK)		1
1	12	74003976	SCREW, SHOULDER		3
1	12	74002809	SHIELD, DEFLECTOR FLUE (BLK)		1
1	13	74005020	SIDE, BODY (RT)		1
1	14	74005021	SIDE, BODY (LT)		1
1	15	74003106	RACK, OVEN		1



**Model Number: CLY1620BDB**  
**BOM/Serial #: CLY1620BDB**  
**Graphic Title: DOOR**

Image	Key	Part Number	Description	Substitution	Qty.
1	1	2401F126-70	PANEL, DOOR (BLK)		1
1	2	74003929	HANDLE, DOOR (BLK)		1
1	3	74002059	SCREW		2
1	4	74004069	SCREW (#10 X 3/4")		2
1	5	12400029	HINGE KIT (RT)		1
1	5	12400028	HINGE KIT (LT)		1
1	6	74004227	LINING, DOOR		1
1	7	3423F001-34	ARM, SPRING		2
1	8	7212P014-60	SEAL, DOOR (TOP)		1
1	9	7212P038-60	SEAL, DOOR (SIDES)		2
1	10	7101P124-60	SCREW WWASHER (CHR)	74003976	4
1	14	74001092	INSULATION, DOOR		1